

Remember to use the Visual Assist  to search for information.

To	Do This
Work Order Completions	<p>Navigation</p> <p>Q1 - Super Backflush by Work Order</p> <p>Steps</p> <ol style="list-style-type: none">1. Scan the Work Order Number2. Enter the Operations Sequence from the work order routing (most work orders have only one operations sequence; enter 1)3. Press Enter4. Enter the quantity of finished products completed on this work order5. If the work order is complete enter Y