

Remember to use the Visual Assist  to search for information.

To	Do This
<b>Attaching an Existing Routing &amp; BOM to Work Order (Standard Items) Through NIS</b>	<p> <b>Work Order Types &amp; Status Codes</b></p> <ul style="list-style-type: none"><li>• WO - Work Order</li><li>• WR - Repair, Maintenance or Warranty</li><li>• 05 - Work Order Created</li><li>• 10 - BOM/Routing Attached</li><li>• 30 - Work Order Printed</li><li>• 45 - Material Issued</li><li>• 95 - Manufacturing Complete</li><li>• 96 - JE Completions Proofed</li><li>• 97 - JE Completions Complete</li><li>• 98 - JE Variances Proofed</li><li>• 99 - Order Complete</li></ul> <p><b>Navigation</b></p> <p>Click NIS State of Nebraska</p> <p>Dist &amp; Mfg - CSI &gt; Manufacturing &gt; Shop Floor Management &gt; Daily Processes &gt; Work Order - Attach BOM/Routing</p> <p><b>Steps</b></p> <ol style="list-style-type: none"><li>1. Click <b>Data Selection</b> check box</li><li>2. Click <b>Submit</b></li><li>3. Click <b>Literal</b> in the <b>Right Operand</b> box</li><li>4. Enter the work order number(s)</li><li>5. Click <b>OK THREE</b> times</li></ol>