

Remember to use the Visual Assist  to search for information.

To	Do This
<p>Creating a Custom Routing Through NIS</p>	<p> Work Order Types & Status Codes</p> <ul style="list-style-type: none"> • WO - Work Order • WR - Repair, Maintenance or Warranty • 05 - Work Order Created • 10 - BOM/Routing Attached • 30 - Work Order Printed • 45 - Material Issued • 95 - Manufacturing Complete • 96 - JE Completions Proofed • 97 - JE Completions Complete • 98 - JE Variances Proofed • 99 - Order Complete <p>Navigation</p> <p>Click NIS State of Nebraska</p> <p>Dist & Mfg - CSI > Manufacturing > Shop Floor Management > Daily Processes > Enter Work Order (or Shop Floor Workbench)</p> <p>Steps</p> <ol style="list-style-type: none"> 1. Browse to find work order 2. Click the row check box for the appropriate work order 3. Click Routing in the Row Exit 4. Enter the Work Center (ie. 46070120 is work center 01 in Branch/Plant 46070020) 5. Enter the Labor Run Hours, this is the total for the work order; 10 items @5 hr/ea = 50 hrs 6. Click OK