




Remember to use the Visual Assist  to search for information.

To	Do This
<p>Printing or Attach & Print a Work Order Through NIS</p>	<p> Work Order Types & Status Codes</p> <ul style="list-style-type: none"> • WO - Work Order • WR - Repair, Maintenance or Warranty • 05 - Work Order Created • 10 - BOM/Routing Attached • 30 - Work Order Printed • 45 - Material Issued • 95 - Manufacturing Complete • 96 - JE Completions Proofed • 97 - JE Completions Complete • 98 - JE Variances Proofed • 99 - Order Complete <p>Navigation</p> <p>Click NIS State of Nebraska</p> <p>Dist & Mfg - CSI > Manufacturing > Shop Floor Management > Daily Processes > Work Order - Print/Work Order - Attach BOM/Routing & Print</p> <p>Steps</p> <ol style="list-style-type: none"> 1. Click Data Selection check box 2. Click Submit 3. Click Literal in the Right Operand box 4. Enter the work order number(s) 5. Click OK TWICE 6. Click the Document Setup Tab 7. Click the OSA Interface check box 8. Click in the box below OSA Interface 9. Click the visual  assist 10. Choose FSOSATXRX 11. Click Select 12. Click OK 13. Click Submit Job from the menu 14. Click Submitted Jobs in the form exit 15. Check row for the submitted job (complete shop packet Job Details will begin with R31415) 16. Click View OSA in the row exit

To	Do This
	17. Check that OSA displays the WO Header page, WO parts list page(s) & WO routing with bar codes 18. Print the OSA to a local printer if not configured to "print immediate"